



EBP® INSTALLATION INSTRUCTIONS

DAVIES, CRAIG EBP® (ELECTRIC BOOSTER PUMP) AND OPTIONS FOR PUMP CONTROL

Congratulations on your purchase of the Davies, Craig EBP®. The EBP® is designed to compliment your existing Davies, Craig EWP® (Electric Water Pump), or belt-driven mechanical water pump, or improve your heater system or engine block circulation. The EBP® can continually circulate water around the engine head, block and by-pass. It has a high flow capacity and has the advantage of running at a speed independent of the engine speed. The EBP® can also be set to continue running with a timer (not supplied) after engine shut down to prevent damaging heat rise.

PLEASE READ THESE INSTRUCTIONS IN THEIR ENTIRETY BEFORE YOU START WORK.

EBP® KIT CONTENTS:

Item No.	Part No.	Description	Qty
1.	9012	EBP®	1
2.	9020	EBP® Adaptors	2
3.	9510	Adaptor Hose	2
4.	9511	Hose Clamps	4
5.	9516	Wiring Harness	1
Not Shown	9901	Installation Instructions	1




Figure 1: EBP and hardware components.

EBP® APPLICATION OPTIONS

The EBP® has been designed for a number of applications, these being:


1. Circulation Pump for LPG Vehicles – The EBP® improves water circulation through the engine block to prevent LPG injector from icing up. Other advantages include a more constant engine temperature and better engine cooling.
2. Heater Booster Pump – The EBP® increases heater performance during normal vehicle operation and enables continued heater usage when engine is off (but IGNITION is ON).

3. Water Pump for Liquid Cooled Motorcycle Engines - The EBP[®] provides liquid circulation independent of the engine speed to provide cooling at all levels. It may be used with the EWP[®] Digital Controller to replace the existing water pump or used with an override switch to compliment the existing system.
4. Multi-Purpose Pump – The EBP[®] may be used in a number of different applications where flow is required, such as irrigation, camping, solar pumps, go-karts or marine operations.

INSTALLING THE EBP[®]

The installation procedure is similar for each vehicle application: the pump is to be installed within the existing hoses. However each application has a different method of use and/or control. These specific differences are described in each appropriate application.

1. The EBP[®] is to be installed in the engine heater hose connecting the thermostat to the back of the engine block. Check the area for available space and shape of the heater hose. The section of the heater hose connected to the front of the block must be connected to the inlet of the EBP[®] and the section of heater hose connected to the back of the engine block must be connected to the outlet of the EBP[®]. “Inlet” and “outlet” of pump may be determined by arrows on the pump or refer to Figure 2 below. The pump inlets and outlets are connected using the hose-clamps provided. Tighten the hose-clamps after a few hours running at temperature and again after 20hrs running.
2. If the existing heater hose diameter does not fit the inlet and outlet of the EBP[®], the plastic adaptors (Item No: 2) and adaptor hose (Item No: 3), may be used to configure a diameter that best suits your hose. The adaptor is connected to the EBP[®] by clamping the adaptor hose to the appropriate inlet or outlet of the pump and the other end to the largest diameter step on the adaptor. Each adaptor has 2 extra diameters to suit hose diameters from 12mm to 19mm. It is suggested that if the second size step is used on the adaptor, the first step should be sawn off to maximise coolant flow. This may be done with a hacksaw or similar device.
3. Once the EBP[®] is installed within the hose, the wiring harness (Item 5) is to be attached to the pump. The wiring harness can be connected to the pump in only one configuration - the release tab on the wiring harness connector must align with the tab-lock of the connector on pump housing.
4. The EBP[®] is then to be wired up as described in each appropriate application.



APPLICATION 1: CIRCULATION PUMP FOR LPG VEHICLES

The EBP improves water circulation through the engine block to improve LPG converter operation. Therefore, it is necessary for the EBP® to be functional all times the engine is running; hence the pump is wired directly to ignition. Other advantages include a more constant engine temperature and better engine cooling when set to continue running after engine shut down.

The EBP® is wired as shown below. Note

APPLICATION 3: MOTORCYCLE WATERPUMP


Two options are available for the EBP[®] in liquid cooled motorcycle engines:

1. With override switch to operate EBP[®] when extra cooling is required.
2. With a thermal switch to operate automatically at a set engine temperature.

MOTORCYCLE EBP[®] INSTALLATION

The installation procedure is similar for each motorcycle option: the pump is to be installed within the existing cooling system hose. However each option has a different method of use and/or control, these specific differences are described in each appropriate option.

1. The EBP[®] is to be installed in the bottom cooling system hose connecting the radiator to the engine block. Check the area for available space and shape of the cooling hose. The section of the cooling hose connected to the radiator must be connected to the inlet of the EBP[®] and the section of cooling hose connected to the engine block must be connected to the outlet of the EBP[®]. "Inlet" and "outlet" of pump may be determined by arrows on the pump or refer to Figure 2 below. The pump inlets and outlets are connected using the hose-clamps provided. Tighten the hose-clamps after a few hours running at temperature and again after 20hrs running.
2. If the existing cooling hose diameter does not fit the inlet and outlet of the EBP[®], the plastic adaptors (Item No: 2) and adaptor hose (Item No: 3), may be used to configure a diameter that best suits your hose. The adaptor is connected to the EBP[®] by clamping the adaptor hose to the appropriate inlet or outlet of the pump and the other end to the largest diameter step on the adaptor. Each adaptor has 2 extra diameters to suit hose diameters from 12mm to 19mm. It is suggested that if the second size step is used on the adaptor, the first step should be sawn off to maximise coolant flow. This may be done with a hacksaw or similar device.
3. Once the EBP[®] is installed within the hose, the wiring harness (Item 5) is to be attached to the pump. The wiring harness can be connected to the pump in only one configuration - the release tab on the wiring harness connector must align with the tab-lock of the connector on pump housing.
4. The EBP[®] is then to be wired up as described in each appropriate application.




OPTION 1: EBP® WITH OVERRIDE SWITCH

The EBP® may be used to compliment the existing cooling system and only be operational when additional cooling is necessary.

1. As described above, the EBP® is to be installed in the cooling system hose between the radiator and the existing water pump. The EBP® itself will not restrict flow in the circuit.
2. The EBP® may be wired with an override switch (not supplied in EBP® kit) as outlined in the wiring diagram below. With this option the switch would be located at an accessible position on the instrument panel.
3. Before the engine overheats close the switch to activate the pump. This in turn will increase the flow within the cooling system and improve the cooling.
4. If the ignition is left on or with the introduction of a timer switch (not supplied) the EBP® can be set to continue running after engine shut down to prevent damaging heat rise.

WIRING DIAGRAM: EBP® WITH OVERRRIDE SWITCH




OPTION 2: EBP® WITH THERMAL SWITCH

This option when combined with a Davies, Craig Thermal Switch (P/No: 0401 or 0402) will turn EBP® on at the temperature you set to boost cooling. The pump will turn off when engine temperature has reduced by 4°C.


The EBP® is to be installed in the cooling system hose as described above between the radiator and the existing water pump. The EBP® itself will not restrict flow in the circuit.

INSTALLING THERMAL SWITCH

1. When the engine is cold remove the top radiator hose at the radiator end. (Refer Diagram next page). Mount the thermal switch to the bracket with the two small screws provided. Mount the bracket onto a panel near the radiator so that the stainless steel bulb will easily reach into the top radiator hose. Ensure that adjustment shaft is accessible. Fix the bracket in place with the two large self-tapping screws provided.
2. Lay the rubber seal along the radiator ferrule and place a section of the stainless steel capillary of the Thermal Switch down the groove in the rubber seal. Keep the capillary loosely coiled and avoid sharp bends. Do not pass the bulb further down the hose than is necessary as the constant movement of the engine in relation to the radiator may cause fatigue of the capillary. The seal and tube may be held in place with insulation tape.
3. Fit the hose and clamp so that the clamp is over the centre of the rubber seal and the clamp screw is in the opposite side of the tube to the capillary and seal. *A good silastic type sealant may be used if there is a persistent leak*



4. Connect the pump wiring harness to the pump. Cut the blue wire before the fuse and crimp the spade terminals (from Thermal Switch packaging) to each end. Connect spade terminals to each pin of thermal switch. The connection order does not matter since both pins have the same polarity. The blue wire provided with the thermal switch can also be used to increase length of blue wire from EBP®, otherwise this can be discarded.



RUNNING THE EBP®

Run the engine and monitor the engine temperature, adjusting the thermal switch dial to turn the EBP® on at the temperature desired. With the thermal switch connected directly to the battery, after a hot shut down, the pump will continue to run and stop engine heat soak. Generally, running the engine slightly colder will increase the power and running the engine slightly hotter will improve the fuel efficiency.

Tighten hose clamps after a few hours running at temperature and again after 20 hours running. Check for leaks.

The EBP® used in conjunction with the EWP Digital Controller (P/No: 8020) may replace your existing mechanical motorcycle water pump in certain situations if the existing motorcycle flow is 15 L/min or less. Refer to EWP® Digital Controller instructions for detailed installation procedures.

Warning: Motorcycles may require special bleeding procedures (not described here) to remove air from the cooling system. The EBP® must be completely flooded with coolant at all times to achieve the life specification of the EBP® and to preserve warranty.

APPLICATION 4: MULTI-PURPOSE PUMP

The unique and robust design of the EBP[®] allows the pump to be used in a number of different applications as to those described above. The EBP[®] is a centrifugal pump with an impeller driven by an electronically commutated motor. This totally removes the problem of brush wear encountered on conventional motors with their mechanical commutation systems. The design ensures a hermetic seal between the pump and the electronic motor without the need for a shaft seal. Through the elimination of the mechanical commutator the durability of the pump is only practically limited by the mechanical life of the rotor bearings. In addition the noise emissions are reduced by the small amount of moving parts. The pump has an axially orientated inlet and perpendicular outlet.

The EBP[®] in fact may be used in all situations that require a water flow-rate of up to 15L/min and where a positive-head is available. Such applications may include:

- ♦ Go-Kart Water Pump – The EBP[®] may replace an existing non-pumped thermosiphon circulation system or compliment the existing system. This is on the condition the system requires 15 L/min or less flow rate.
- ♦ Camping/Caravan/Recreation- the EBP[®] could be used in a variety of arrangements where pumping is necessary: outdoor showers, sinks, toilets, taps etc.
- ♦ Marine – The EBP[®] may be used to compliment the existing water pump on inboard motors similar to the automotive needs described earlier, increased cooling and the prevention of heat soak after engine shut down.

Warning: The EBP[®] is only splash resistant, therefore to achieve life specification and preserve warranty at no point should the EBP[®] be fully submerged.


- ♦ Solar Heating – The EBP[®] may be used to circulate water through 12V solar hot water systems.
- ♦ Irrigation – The EBP[®] may be used to pump water through irrigation systems, which require water flow of less than 15L/min.

Other situations not described above may be suitable for the EBP[®]. The technical specifications for the EBP[®] as well as the performance curve of the EBP[®] have been detailed below to help with any decisions on other applications. Advice is available from Davies, Craig and we would very much appreciate feedback on your experiences.

TECHNICAL SPECIFICATIONS:

Motor	12V Brushless
Operating Voltage	9V to 15V DC
Max. Current Draw	1.3 Amps
Pump Design	Recirculating* Centrifugal
Drive	Magnetic – no seals
Operating Temperature	-40°C to +120°C (-10°F to +250°C)
Burst Pressure	250 KPa (36 PSI)
Flow Rate	15 L/min (4 gal/min) at 10 KPa
Weight	245 g (0.54 lbs.)

* A recirculating pump requires a positive head of coolant at all times – do not run dry.



These installation instructions will suit most situations but there are many conditions of engine design, environment, and the kind of motoring involved, which may call for other arrangements not described here. Advice is available from Davies, Craig and we would very much appreciate your feedback.

WARNINGS

Engine temperature must be monitored very closely at all times but especially immediately after installation and until pump operation and capacity have been proved.

The EBP® can handle most rust particles and sludge found in cooling systems but large rust particles should be flushed from the radiator before the EBP® is installed.

Some vehicles may require special bleeding procedures to remove air from the cooling system not described here. The EBP must be completely flooded with coolant at all times to achieve the life specification of the EBP and to preserve warranty.

Do not use the vehicle's engine management system or wiring connected to the vehicle's engine management system as an ignition source because it may cause failure of the management system and/or the electrical system. The ignition source must be a steady positive supply of up to 15VDC.

All wiring must be kept away from potential hot spots, such as exhaust manifolds, during installation to ensure proper EBP® operation and to prevent any subsequent damage caused by wiring failure.

WARRANTY

We hereby guarantee that for a period of two years or 2000 hours continuous running (whichever is the lesser) from the date of purchase, we shall carry out, free of cost, any repairs that are reasonably necessary to correct any fault in the operation of your Electric Booster Pump (EBP®) provided that such a fault is directly attributable to a defect in the workmanship or materials used in the manufacture of the part(s) and is not due to installation other than described in these instructions.

DAVIES, CRAIG PTY. LTD.

Warranty registration now available on-line at www.daviescraig.com.au

P/No: 9901

30/05/07



EBP® and hardware components.